



PLUG PIPE PENETRATIONS & SUFFICIENTLY FASTEN PLUGS TO PREVENT WET CONCRETE FILL FROM ENTERING PIPES

SECTION C

SCALE: 1/2" = 1'-0"

NOTES:

1. THE EXISTING CONCRETE CHAMBER IS CURRENTLY FILLED WITH SOIL. ALL SOIL MUST BE REMOVED AND ALL WATER MUST BE EVACUATED FROM THE CHAMBER.
2. PLUG & FASTEN THE PLUGS AT THE THREE PIPE PENETRATIONS.
3. POUR THE CHAMBER FULL WITH CONCRETE FILL.
4. AFTER WAITING A MINIMUM OF 24 HOURS AFTER THE CHAMBER IS FILLED WITH CONCRETE FILL, THE CONCRETE SIDEWALK SHALL BE INSTALLED.

	12/12/21	46 TH STREET
	THOMAS J. LAROCO	CHAMBER ABANDONMENT SECTION